

Tableau 3 - Solidité

BLANC	Température de cuisson	Cran	Casse après la torsion n°
Fimo Pro	110°C	6	8
		8	3
Fimo Soft	110°C	4	1
		6	1
		8	1
	140°C	4	5
		6	2
		8	1
Sculpey Premo	130°C	6	6
		8	4
Sculpey III	130°C	2	5
		4	1
		6	1
		8	1
	150°C	4	1
		6	1
		8	1
Sculpey Soufflé	130°C	4	8
		6	5
		8	9
	150°C	6	9
		8	7

BLEU	Température de cuisson	Cran	Casse après la torsion n°
Fimo Pro	110°C	4	5
		6	3
		8	5
	140°C	6	9
Fimo Soft	110°C	4	1
		6	1
		8	1
	140°C	4	3
		6	2
		8	1
Sculpey Premo	130°C	6	6
		8	4
Sculpey III	130°C	0	10
		2	6
		4	1
		6	1
		8	1
	150°C	2	5
		4	1
		6	1
		8	1
Sculpey Soufflé	130°C	6	10

DORE	Température de cuisson	Cran	Casse après la torsion n°
Fimo Effect	110°C	4	7
		6	6
		8	4
	140°C	4	7
		6	7
		8	1

TRANSLUCIDE	Température de cuisson	Cran	Casse après la torsion n°
Fimo Effect	140°C	4	6
		6	6
Pardo Pro Art	120°C	8	10
		9	5
Cernit	110°C	8	2
		9	4
	140°C	8	7
		9	6

